

COVERMATE LOADING

1. Position rack for loading.
2. Lock all floor brakes.
3. Remove tape from cover seams.
4. Load the first cover on the bottom roller completely using the quick clips and hand/power crank.
5. Secure the cover in place with tape/Velcro strap.
6. Unlock all floor brakes.
7. Turn rack 180° while re-positioning it to load the next cover.
8. Lock all floor brakes.
9. Load the cover onto the bottom roller on the opposite side of the rack completely.
10. Secure the cover in place with tape/velcro strap.
11. At this point, the bottom rollers on both sides of the rack should be completely loaded.
12. Continue loading covers from **bottom to top and side to side** repeating the instructions above.
13. Never load all covers on one side of the rack before loading covers on the other side of the rack.
14. Never load covers from top to bottom.

COVERMATE UNLOADING

1. Position rack for unloading.
2. Lock all floor brakes.
3. Unload the first cover from the top roller completely.
4. Unlock all floor brakes.
5. Turn rack 180° while re-positioning it to unload the next cover.
6. Lock all floor brakes.
7. Unload the cover from the top roller on the opposite side of the rack completely.
8. At this point, the top covers on both sides of the rack should be completely unloaded.
9. Continue unloading covers from **top to bottom and side to side** repeating the instructions above.
11. Never unload all covers on one side of the rack before unloading covers on the other side of the rack.
12. Never unload covers from bottom to top.
13. When covers are unloaded and in place, tape all cover seams securely.