

GYM FLOOR COVER MAINTENANCE

Before and After Every Use:

1. Cover sections shall be inspected for visible damage, i.e. cuts, tears or burns. ALL damaged areas should be repaired in accordance with the *REPAIR INSTRUCTIONS* manual.
2. Cover sections shall be swept and spills damp mopped after every use.
3. Regular washing can be carried out to remove surface residue from the cover sections. Lukewarm or cold water with a mild detergent should be used. CleanMate Antistatic Cleaner or Varsol may be used on tough spots, provided affected area is washed with soap and water immediately afterwards. Always remove excess water to prevent water staining.
4. Care must be exercised when installing or removing cover sections to ensure that no product damage occurs.